

**Zhongxing Landmark Series**

**MAINTENANCE MANUAL**

**Chief Editor: Zhang Xiaping Liu Hongju Liu Jinyan**



## Preface

This manual provides the general methods for repair of chassis and body of Zhongxing **Landmark** Series vehicles.

Applicable Vehicle Type:

BQ6473G, BQ6473SG, BQ6473RG and BQ6473RSG

For the maintenance specifications and repair procedures belonging to Zhongxing Series vehicles and excluded in this manual, refer to the following manuals:

- U CYQD29TI QD32T Engine Maintenance Manual
- U 4G22D4 Engine Maintenance Manual
- U G4BA Engine Maintenance Manual
- U XG-491 Engine Maintenance Manual
- U 8B3 Vehicle Transmission Maintenance Manual
- U 8D1 Vehicle Transmission Maintenance Manual
- U 8C2 Transmission Maintenance Manual
- U 035C4 Transmission Maintenance Manual
- U ATC750 Maintenance Manual

This manual is mainly used for repair of the above-mentioned vehicles. Along with the uninterrupted modification, upgrading and changes to the specifications and procedures, this manual may have difference to the actual vehicles. In such case, the actual vehicle is governing without any notice.

You are welcome to give your comments.

<b>Compiled by:</b>	Ding Fenghai	Chen Hefeng	Huang Enli
	Guo Mengmeng	Zhang Jilong	Ge Zhonglou
	Liu Ermin	Li Hong	

<b>Examined by:</b>	Zhu Penghua	Jia Shaohui	Zuo Tieyu
	Li Zixin	Yu Yuanhai	

**Approved by:** Yan Feng

Hebei Zhongxing Automobile **Manufacturing** Co., Ltd

## Table of Contents

I	Engine
II	Clutch
III	Drive Shaft
IV	Gearbox
V	Transfer Case
VI	Suspension and Axle
VII	Steering System
VIII	Brake System
IX	Cooling System
X	Air Conditioning System
XI	Electric System
XII	Sunroof

Appendix Schematic Diagram of Electric System